

## Genesys™ / ZUP - USB Solutions

The most cost effective way to connect a Genesys™ or ZUP to a computer via its USB interface is to use our GEN-232-9 cable (RJ45 to 9 pin serial D type connector) and a USB to serial adapter.

- Easy connection of Serial device through USB port
- A cost effective external solution is available from supplier Digitus  
Part No. : DA-70156  
Driver/ Manuals are available via Websites
- Compliant with USB 2.0 Standards  
Supports RS-232 Serial Interface
- Supports Windows 7, Vista, XP, Mac OS X and Linux
- Part Nos.:                   USB- Adapter:   ACC-GEN-337848  
                                  Serial Cable:    GEN-232-9

